

Replacing the bypass rod:

1. You will need: the bypass plate, the rod, and a bolt to attach the two of them. We've used a 5/16" X 2 1/2" with a Nylock nut.
2. The bypass plate must be reinserted into the stove first. You would put it in so that it looks like this when you are facing the firebox looking into the stove:



3. Next you will need to insert the bypass rod back into the furnace and slide it into place in the plate like this:



4. Finally, you will want to line up the two holes, and attach them with the bolt.

